

PRODUCT MANUAL >>>

IMETER-WIFI QUICK INSTALLATION AND WIFI SETUP

1. Hardware Installation

1.1 Packing List


No.	Item	Qty	Note
1	iMeter-Wifi	1	Wifi module embedded
2	Current Transformer	1	CT already connectd to Meter
3	2.4G Antenna	1	

1.2 Hardware Appearance



1.3 Hardware Installation

Step1:L/N WIRE and aerial connection.




Step2:C/T connection.

First,open the C/T;

Then,View the bottom-marked current flow of C/T,grid-L wire across C/T from bottom-marked L to N;

Last,close the C/T.



grid-L wire across C/T from bottom-marked L toN



Note: Electrician license maybe required for installer according to your local law.

2. WiFi Setup


2.1 Enter to setting page

- Use your smart device's WiFi connection setup, connect to the iMeter's network, which will show up as iMeter xxxxxxxx (xxxxxxxx is a unique SN of iMeter).
- No password to connect to the iMeter's WiFi network




Tips: Any smartphone, tablet or computer can be used for this process

- Whilst connected to the iMeter's network, open a web browser and navigate to http://11.11.11.1/
- Enter the username "admin" and password "admin" (no upper-case characters) and log into the webpage.



Tips: Any smartphone, tablet or computer can be used for this process


- The "iMeter WiFi Guick Setup" webpage is displayed.
- You need to make a copy of SN number for the future use in log in the lammeter system (step 3.1)




Tips: Any smartphone, tablet or computer can be used for this process

2.2 Connect to your home WiFi network

- WiFi settings configuration
- Click "WiFi Networks" or or manually input your home WiFi network's SSID
- 2. Input your home WiFi netwrok's password as Key
- 3. Click "Save&Reboot"



Check if the iMeter gain the IP address after rebooted.
 Click "More" for details.



• Click "WiFi Networks" to search your home WiFi network. Ensure the signal strength is stronger than 50%


DEVICEBIT iMe	eter WiFi Quick Setup
Return Available Wireless Network	
SSID	Signal
CMCC-laohe	100%
Solax 10288376	72%
<u>lrz</u>	55%
CMCC-2303	50%
CMCC-2415	42%
CMCC-BJSD2213	32%
Refresh	

3. Registration on lammeter

Confirm the WiFi setup has done successfully (WIFI indicator of iMeter is on in Red).


3.1 Sign up on lammeter

- 1. Visit website https://www.iammeter.com
- 2. click "System" on top menu bar
- 3. Click "Sign up" and fill up all the information on "Sign up" page. Fill in the SN you copied previously in SN column.




3.2 Set Location and Time Zone

- Log in "lammeter" with your username and password
- Go to "My palce" and set your location and time zone.
 Ensure you set the correct time zone.



3.3 Check online data

• Check online data, report and more function in Tammeter



lammeter System

Centralized Power Monitoring Multi-level Managenent Real-time Alarm Notification



- | Coy | Mointh | Total | Cotal | Cotal
- Monitor your energy consumption online anytime from anywhere
- All MODBUS, RTU meters can be connected to the plafform
- Android/IOS App available on Apple Store and Google Play

For details please visit https://www.iammeter.com

iMeter - WiFi

- Quick installation
- High Accuracy

Easy setup

Clouding Service



LED	Status	Description
BUIN	Solid Green	iMeter is powering on
RUN	Off	iMeter is powering off
DEV.	Solid Red	CT's polarity is reversed (refer to bottom mark)
	Off	CT's polarity is correct
AAUEL	Solid Red	iMeter is connected to router
	Off	iMeter is not connected to router



IOS APP DOWNLOAD



ANDROID APP DOWNLOAD



Copyright DeviceBit. All Rights Reserved.