



QUICK START OF TEMPERATURE (& HUMIDITY) SENSOR

1. Standard Package


1 Wi-Fi Temperature Monitor



2 Wi-Fi Temperature & Humidity Monitor




2. Wi-Fi Setup




1 Step1

- Use your smart device's WiFi connection setup, connect to the monitor's network (show up as eMonitor_xxxxxxx)
- xxxxxxxx is a unique SN of iMeter
- No password required



2 Step2

- Whilst connected to the monitor's network, open a web browser and navigate to <http://11.11.11.1/>
- Enter the username "admin" and password "admin" and log into the configuration webpage.




3 Step3


- Click "Wi-Fi Networks" to search and select your home Wi-Fi Network as SSID
- Enter the password for your home Wi-Fi Network as Key.
- Click "Save&Reboot"

Tips

- ① After connected to the your home Wi-Fi network, the monitor's Wi-Fi access point signal (eMonitor_xxxxxxx) will be hidden for security reason;
- ② You can find your monitor in the network of your PC which is connected to the same home Wi-Fi network.



3. Sign up by mobile App




1 Download mobile app

2 Click "Sign Up" to fill in the information.

Tips

SN: The serial number of your monitor. You can find it on the label attached to the product.

4. Set the time zone



Tips


Time zone must be set according to your location for correct data display and report on time basis.

5.Edit your device



Tips You can set the name, normal value range and alarm notification settings if needed.

6.View the data



1 Date view on app

2 Date view on webpage

Tips Please visit <https://www.lwkits.com> for login on web portal. Same username and password with app